

How to install AUC mounting plate

1. Install L-bracket onto countersunk screw hole on corner block.



2. Install mounting plate onto L-bracket with screws.




AUCG series

CORNER GUARD for AU□ series



AUCG dimensions



■ DXF/DWG/PDF drawings available on our website.

- Spare corner guard for AUGH, AUG and AUGE series. AUCG corner guard can also be installed on AU, AUP, AUPE, AUX, and AUXE series enclosures.
- 4 colors available: Black, Gray, Navy, and Red. Retailed as a pack of 8pcs.

Product no. / Details

Product no.				Weight (g)	Pack of
● Black	● Gray	● Navy	● Red		
AUCG-1B	AUCG-1G	AUCG-1N	AUCG-1R	9.5	8

AEG-1000

EMC SHIELDING GASKET for AU□ series




EMC
Shielding



- Spare EMC shielding gasket for AUPRE, AUXRE, AUGE, AUPE, and AUXE series enclosures. Installation on AUP and ARPR series is possible to allow it to be EMC shielded.

Cross section view



Product no. / Details

Product no.	Material	Color	Sales unit
AEG-1000	Conductive fiber UL94V-0	Metallic gray	1000mm x 1 pc